


CARTRIDGE SHOULD BE KEPT AT 70° F+ FOR BEST RESULTS


INSTRUCTIONS FOR USING CARTRIDGE UNIT

1

SHAKE WELL
BEFORE USE




Unscrew Locking
Nut and
Remove D Caps




2

Place Static Mixer
Over Cartridge
Neck and Secure
Tightly with
Locking Nut





3

Pull Back
Pistons in Gun
and Securely
Load Cartridge
in Cradle



4


Hold Gun
Straight Up at
a 90° Angle
and Slowly
Pull Trigger to
Purge Air from
Unit. Drive
Material to
Top of Mixer.



5


Tilt Gun
Down and
Squeeze First
2-3 Shots of
Material into
A Disposable
Cup, Etc.

Gun Should Be
Tilted Down
Whenever
Dispensing or
When Cartridge
is Being Used.



6

To Re-use Cartridge, Tilt
Cartridge Unit Down,
Remove Mixer,
Wipe Excess
Material Off
Cartridge Neck,
Then Replace
D-Caps and
Screw on
Lock Nut.
Use New
Mixer
with
Next
Application.



INSTRUCTIONS FOR USING THE CARTRIDGE UNIT (CONTINUED)

DEFECT PREPARATION IS CRITICAL!


Spal-Pro 2000 can be used to permanently repair a variety of common floor defects, but proper defect preparation is critical in ensuring that your repair will last. There are two important factors in repairing any floor defect:

REPAIR AREA MUST BE DRY AND COMPLETELY CLEAN
OUTSIDE OF REPAIR AREA SHOULD HAVE A VERTICAL EDGE...DO NOT FEATHER EDGE REPAIRS!


Edges of repair can be defined using a concrete saw or right angle grinder with a diamond/abrasive blade. A cold chisel is also acceptable. Vertical edge of repair area should be 1/2" minimum or 3/4"+ (preferred). Any concrete that is not structurally sound should be removed along with any debris, dirt, oils, etc.

THESE ARE ABBREVIATED REPAIR INSTRUCTIONS. FOR MORE DETAILED REPAIR SPECIFICATIONS REQUEST OUR BASIC GUIDE TO FLOOR REPAIRS by calling 800-223-6680 or download at www.metzgermcguire.com.


Random Cracks



Gouges, Holes



Spalled Joints




INSTRUCTIONS FOR FILLING FLOOR DEFECTS

1 Defects Less than 2" Wide

For Narrower Joints, Cracks, Pop-Outs, etc., Prepare Area as Outlined in Defect Preparation and Slightly Overfill Defect With Material.

2
Allow Material to Cure into a Solid and Razor Off Flush with Floor Surface Using Tile Scraper with Disposable Blade.



1 Defects 2" or Wider

For Wider Joints, Cracks, Pot Holes, Etc., Prepare Area as Outlined in Defect Preparation. Efforts Should Be Made to Fill Defect Flush as Shaving is Very Difficult for Wide Areas. If Material is Overfilled Slightly, It Can Be Sanded Down Using a Sanding Block or Sander at Low Speed. Joints and Cracks Should Be Monitored To Ensure Material Does Not Sink and Leave a Concave Profile. Apply Additional Material if Necessary.

